



Schneller Manufacturing Inc.

8052 118<sup>th</sup> Ave N. Largo, Fl. 33773

Phone (727)549-2100 Fax (727)549-2152

[www.schnellermanufacturing.com](http://www.schnellermanufacturing.com)

## Assembling Your S.S. Wheeled Shooting Stool

To begin assembling your SS Shooting Stool, carefully unpack all components.

### Parts List:

- Three (3) S.S. tubing pieces
- Two (2) wheels
- One (1) axle
- A small plastic bag containing the following hardware.
  - Two (2) ¼" X 2 ½" Hex Bolts
  - Two (2) ¼" X 2 ½" Carriage Bolts
  - Two (2) ¼" Wing nuts
  - Two (2) ¼" Nylocks
  - Six (6) ¼" Flat Washers
  - Four (4) Special Curved Washers
  - Two (2) Spring Clips
  - Two (2) ½" Flat Washers

The main upright handle is already full assembled.

For photos of the **S.S. Shooting Stool** as it is being assembled, please visit our **Assembly Instructions Page** at [www.schnellermanufacturing.com](http://www.schnellermanufacturing.com). You will find the link on the **FAQ's** page as well as the **S.S. Shooting Stool** page.

The fold down table is shipped with a PVC covering to protect the aluminum finish. You may wish to remove it after assembly of your Shooting Stool, but removal is not necessary. The PVC covering will continue to provide long term protection for your table. This coating cannot be put back on once it is removed.

First place your bag on the two smaller stool halves. Be sure you have the bag facing in the direction you want before you proceed.

Next install a 2 1/2" bolt in either side of the two halves. Be sure to install a 1/4" flat washer on the inside, outside, and in between each of the tubing pieces on both sides. Install a 1/4" Nylock on each bolt. Do not over tighten these bolts as it will make the stool harder to collapse. The Nylocks will keep the bolts from unscrewing. Tightness is not important.



## Schneller Manufacturing Inc.

8052 118<sup>th</sup> Ave N. Largo, Fl. 33773

Phone (727)549-2100 Fax (727)549-2152

[www.schnellermanufacturing.com](http://www.schnellermanufacturing.com)

Next install the aluminum axle through the holes in the end of the stool halves. Put a 1/2" flat washer on the outside of each tube. Then install the wheels. Next place a spring clip on the end of the axle.

Locate the holes provided for mounting the long handle. Place a 2 1/2" carriage bolt, with a special curved washer through the tubing on either side. Next place the long top handle under the tubing sides, allowing the carriage bolts to pass through the holes provided. Put another curved washer on each bolt, and screw on a wing nut. Be sure that the square of the carriage bolt fits into the square of the curved washer. It is designed to keep the carriage bolt from turning when tightening the wing nut.

That's all there is to it! Now go and enjoy your new S.S. Wheeled Stool. If there are any questions, or suggestions, please feel free to call, or e-mail anytime.

Thanks for purchasing our product.

Bob Schneller

P.S. Please visit our website at [www.schnellermanufacturing.com](http://www.schnellermanufacturing.com) and sign up for the free newsletter. It will have all the new products by **Schneller Manufacturing**, as well as sale and promotional items.